

# Fitting Instructions



SKU

PRODUCT

**T4Z493**

**TAG Heavy Duty Towbar to suit  
Hyundai Tucson (08/2004 -  
01/2010), KIA Sportage  
(04/2005 - 08/2010)**



Scan for latest  
version of these  
instructions

## SPECIFICATIONS

- Towbar Class: Standard Duty
- Towing Capacity: 1500kg

## IN THIS GUIDE

- Fitment Instructions
- Torque Settings
- Warranty Info

# Towbar Fitting Instructions



## Step-By-Step Instructions

### Warning:

Safety First: Always use correct safety equipment.

This towbar is NOT to be drilled, cut, welded or modified in any way.

Check the surrounding area before drilling into chassis or body panels for fuel lines, wiring harnesses and other components that may be a hazard.

### General:

Before fitting this towbar read fitting instructions and check installation hardware is correct.

Check that the towbar is suitable for the vehicle and be wary of any changes to the vehicle design that may conflict with the fitting of this towbar.

After drilling, blow any filings clear, remove any swarf and treat exposed metal with a rust inhibitor.

If this vehicle requires a bumper cut out, please check to make sure that you measure twice and check twice before cutting any panels as some bumper profiles can change.

If you are not sure then ask your towbar supplier.

Tighten all bolts as specified on the last page.

1. REMOVE ALL BOLTS FROM TOWBAR.
  - 1.1. RELEASE EXHAUST FROM REAR HANGERS.
  - 1.2. REMOVE SHIPPING HOOK/AND DISCARD.
  - 1.3. BUMPER CUT TO BE MADE/90 MM WIDE X 20MM DEEP FROM CENTRE BOTTOM OF BUMPER.
2. INSTALL TOW BAR USING 8 X M10 BOLTS AND WASHERS PROVIDED AND TIGHTEN TO SPECIFIED RATINGS.
  - 2.1. REFIT EXHAUST ONTO HANGERS.
3. INSTALL BALL MOUNT WITH PIN AND CLIP PROVIDED.
4. ATTACH RATINGS STICKER TO DRIVERS SIDE DOOR PILLAR.

# Towbar Fitting Instructions



## Torque Table for Bolt Tightening

<b>Metric GRADE 8.8</b>	<b>UNC GRADE 8</b>
M6 – 12.5 Nm	3/8 – 50 Nm
M8 – 30 Nm	1/2 – 125 Nm
M10 – 60 Nm	5/8 – 245 Nm
M12 – 103 Nm	
M14 – 167 Nm	
M16 – 270 Nm	