








Read this full instruction prior to commencing assembly and fitment of Ridge Mount system.

CONTENT - CHECK ALL PARTS ARE CORRECT BEFORE PROCEEDING


A		Ridge Mount (Pair)	1
B		Stud Plate	6
C		M8x25mm Cap Screw	20
D		M8x17mm Flat Washer	44
E		Rubber Washer	8
F		M8 Nyloc Nut	24
G		Butyl Patches	16

TOOLS REQUIRED

- 6mm allen tool.
- 13mm socket wrench.
- Step ladder.
- Butyl mastic sealant.
- Trim tools.


1

Move to the side of the vehicle. Use a step ladder to get access to the vehicle roof.




2


Using trim tools, carefully pry off the caps at either end of the factory rails.



Remove the cover from the outside of the vehicle, levering the plastic inward toward the center of the roof.




With a 13mm socket, remove the M8 hardware both front and rear, now exposed on the rails.




3

Remove the factory rails.




4

Clean the roof gutter channel where the factory rails have been removed.
 (A OPTIONAL) Using butyl mastic, apply the sealant to all exposed holes in the roof.
 (B) Add **2x butyl patches** to the exposed threads in the roof.




5

Place rubber washers over all the exposed threads in the roof gutter channel.




6

Install the M8 hardware as shown below.




7a

Place the rails onto the roof of the vehicle. Tighten the M8 hardware with a 6mm allen key to 4-5Nm.



7b



Install the stud plates as shown. Tighten with a 13mm spanner.




PLATFORM FITMENT

8


Install the Kaymar Platform as per corresponding instructions.



Note:



Wiring can be run and secured on the underside of the mount rail as shown.



IMPORTANT - READ BEFORE USE

Please ensure the system is fitted in accordance with the fitting instructions.
It is important that you observe all outlined below.



LOAD RECOMMENDATIONS

- Routinely and regularly check the proper functioning of the system. Check all fixtures at regular intervals.
- Do not use an automatic carwash with system installed.
- Maximum load capacity of the system is 661lbs/300kg under static conditions.
- Maximum load capacity of the system is 220lbs/100kg under dynamic including off-road conditions.
- Do not exceed vehicle manufacturers recommended load rating if it is lower than the maximum load capacity specified in this document (i.e., 220lbs/100kg).
- Ensure any load carried is evenly distributed.
- Actual load on vehicle Roof (Refer to owner's manual) = Weight of Roof rack system / Ridge Mount + Weight of Platform + Weight of cargo.
- Actual load on rack system (Refer to product instructions) = Platform weight + cargo.

WARRANTY INFORMATION

For full Warranty details refer to Kaymar website.

Kaymar.com.au

NOTE

All content subject to APG copyright.