









Read this full instruction prior to commencing assembly and fitment of Ridge Mount system.


A		Ridge Mount (Pair)	1
B		Stud Plate	6
C		M8 x 25mm Cap Screw	12
D		Rubber Washer	16
E		M8 Nyloc Nut	24
F		M8 x 17mm Flat Washer	52
G		M8 x 30mm Cap Screw	16
H		M8 Spring Washer	16

TOOLS REQUIRED

- 6mm allen tool.
- 10mm socket wrench
- 13mm spanner.
- Step ladder.
- Butyl mastic sealant.
- Flat blade screwdriver.
- Trim removal tool.




FACTORY RAIL REMOVAL - FOR BARE ROOF TURN Pg 5 1

Move to the side of the vehicle. Use a step ladder to get access to the top of the vehicle.






2

Using a trim removal tool, carefully pry off the rail covers at the front, middle and rear.





3

Using a 13mm socket wrench, carefully remove the bolts holding the rail in place.



4


Carefully remove the factory rails. Clean the roof of the vehicle thoroughly.



BARE ROOF INSTALL


5

Carefully remove the 8 mounting point covers from the roof.




6


- 1 - Place rubber washers over all the exposed threads in the roof ditch.
- 2 - Apply butyl mastic to all these locations as shown.




Assemble M8 hardware into the Ridge Mount Rails as shown.




Install the Ridge Mount hardware as shown below. Tighten with a 13mm spanner.



Place the Ridge Mount assembly onto the roof. The M8 hardware will pick up the factory threads in the roof.





Tighten the M8 hardware with a 6mm allen key to 4-5Nm.
 Note: Access hardware through cutouts on side or holes located on top of the rail.




PLATFORM FITMENT

10


Install the Kaymar Platform as per corresponding instructions.



Note:



Wiring can be run and secured on the underside of the mount rail as shown.



IMPORTANT - READ BEFORE USE

Please ensure the system is fitted in accordance with the fitting instructions.
It is important that you observe all outlined below.

**LOAD RECOMMENDATIONS**

- Routinely and regularly check the proper functioning of the system. Check all fixtures at regular intervals.
- Do not use an automatic carwash with system installed.
- Maximum load capacity of the system is 661lbs/300kg under static conditions.
- Maximum load capacity of the system is 220lbs/100kg under dynamic including off-road conditions.
- Do not exceed vehicle manufacturers recommended load rating if it is lower than the maximum load capacity specified in this document (i.e., 220lbs/100kg).
- Ensure any load carried is evenly distributed.
- Actual load on vehicle Roof (Refer to owner's manual) = Weight of Roof rack system / Ridge Mount + Weight of platform + Weight of cargo.
- Actual load on rack system (Refer to product instructions) = platform weight + cargo.

WARRANTY INFORMATION

For full Warranty details refer to Kaymar website.

Kaymar.com.au

NOTE

All content subject to APG copyright.