



**HOLDEN CAPTIVA 7**  
**CARGO BARRIER USER INSTRUCTION**  
**Part # 207350 2 POSITION**  
VEHICLE YEARS OF MANUFACTURE - From January 2014



This cargo barrier is capable of being located in two positions, behind the 2nd row of seats with the seats in an upright position, and behind the 1st row of seats with the 2nd row of seats in their folded position, using accessory kit #207352.

The cargo barrier is designed, manufactured and fitted to decrease the impact hazard in an accident to occupants from cargo carried within the interior cargo space of the vehicle. In the event of an accident, a cargo barrier can reduce injuries caused by cargo intruding into occupant's space.



## **WARNINGS**

- **Strict compliance with fitting instructions is essential for this safety product to meet its rated capacity. Refer user instructions regarding correct usage of the cargo barrier.**
- **Do not modify cargo barrier in any way.**
- **Do not use this cargo barrier in any other vehicle for which it is not designed.**
- **Modifications to the cargo barrier or its fixings or use in any other vehicle for which it is not designed may void the load rating and warranty.**
- **Do not attach the cargo barrier to the vehicle using seat, seat belt or child restraint anchorage's.**
- **Where high tensile threaded fasteners are used, the cargo barrier must be installed using the size and grade fasteners specified by Milford Industries.**
- **Do not drill, rivet, adhere or attach objects to the front or rear of the cargo barrier.**
- **Do not place smaller items, that may bypass the cargo barrier in the event of heavy braking or collision, near the edges of the barrier.**
- **Position the load against the cargo barrier.**
- **When load is positioned against cargo barrier, secure the load with a restraint system.**
- **During a collision moving cargo may damage seat belts or tether straps of a child restraint device, or its anchorage. Load should be carefully positioned so as not to come in contact with these items.**
- **Do not obstruct seat belts or child restraints, or their operation.**
- **Long thin items of cargo should be positioned in the vehicle with the long axis across the vehicle to minimise the penetration risk.**
- **If involved in an accident or accidentally damaged, the cargo barrier should be replaced and the anchorage's repaired to as new condition.**
- **Clean with soap and water only. Do not use solvents or chemicals. Discard cargo barrier if it becomes rusted. Do not expose to direct sunlight for long periods.**
- **It is extremely dangerous to ride in the cargo area of the vehicle behind the cargo barrier. It is recommended that the cargo barrier be removed. In a collision people or children riding unrestrained in these areas are more likely to be seriously injured or killed.**
- **Never leave a child in the vehicle unattended, particularly in the rear cargo area. The cargo area should never be used as a play area for children.**
- **The cargo barrier may deform and significantly intrude into occupant's space in an accident.**
- **Remember that the tailgate cannot be opened from inside the cargo area.**
- **The fixed labeling should not be removed from the cargo barrier.**
- **Failure to comply with warning notes may prevent the barrier protecting the occupants.**
- **Parents should explain to children how and when to use *EMERGENCY ESCAPE HAMMER* attached to cargo barrier.**
- **Do not remove the rating plaque from the cargo barrier.**


### **NOTICE TO INSTALLERS & DISTRIBUTORS**

***Please ensure User Instructions are left with vehicle owner after installation.***

# **HOLDEN CAPTIVA 7** **CARGO BARRIER USER INSTRUCTION** **Part # 207350 2 POSITION** VEHICLE YEARS OF MANUFACTURE - From January 2014



## **FRONT POSITION ACCESSORY KIT #207352**






**INSTALLATION OF CARGO BARRIER**  
**'Behind 1st row of seats'**

1. Lay the 2nd row seats down flat.
2. Move the front row seats forward on their sliders to allow manoeuvring space.
3. If moving from the behind 2nd row seats position undo all securing Milbolts.
4. Lay the cargo barrier on its back (meshed side) in the cargo area.
5. Attach the support legs to the bottom cargo barrier brackets using 34mm Milbolts.
6. Manoeuvre the cargo barrier into position behind the 1st row seats with the support legs sitting on the floor and the rating label (meshed side of cargo barrier), towards the rear of the vehicle.
7. Attach the tube extension straps to the top cargo barrier straps using 19mm Milbolts. (2 per strap).
8. Attach the other end of the tube extension straps to the roof mounts using 44mm Milbolts with wave washers under their heads.
9. Attach the twisted ends of the front position bottom straps to the bottom mounts using 24mm Milbolts with wave washers under their heads.

Note: For vehicles with a sunroof fitted the front position bottom straps should point down at the front as shown. For vehicles with no sunroof fitted the front position bottom straps should point up at the front as shown.

10. Working on one support leg at a time undo the securing Milbolt.
11. Place the bottom front position strap over the support leg bracket.
12. Replace the Milbolt and tighten.
13. Repeat on the other side.
14. To prevent any lateral movement tie the front position bottom straps to the child restraint mounts in the seat backs, using the Velcro ties normally used to secure the front position straps.




**IMPORTANT NOTE: Check that all bolts and screws are tight and re check periodically.**



## **INSTALLATION OF CARGO BARRIER** **'Behind 2nd row of seats'**

1. Lay the 2nd row of seats down flat to allow manoeuvring space for cargo barrier.
2. Ensure the cargo barrier straps are pivoted towards the meshed side of the cargo barrier.
3. Manoeuvre the cargo barrier into the behind 2nd row seats position with the rating label (meshed side of cargo barrier), towards the rear of the vehicle.
4. Attach the top straps to the roof mounts using 44mm Milbolts with wave washers under their heads.
5. Attach the bottom straps to the bottom mounts using 24mm Milbolts with wave washers under their heads.
6. Tighten all Milbolts.
7. Reposition the 2nd row seats.



**IMPORTANT NOTE:** Check that all bolts and screws are tight and re check periodically.